

# **RMC SUNPRIMER HWP**

Rubio® Monocoat Sunprimer HWP is a water-based primer which limits the effects of UV light and which can be used as an optional primer when applying a finishing coat of RMC Hybrid Wood Protector on vertical exterior wood.

RMC Sunprimer HWP - which is always applied in the same colour as the RMC Hybrid Wood Protector - guarantees the deep penetration of colour pigments which results in an intense colour.

### **PRODUCT INFORMATION**

## > Unique characteristics

- Ready for use
- · Retains the natural look of the wood
- Provides a deep and intense colour
- · Provides better cover and a more uniform effect
- 20 unique colours
- · Only applicable on vertical wood

## > Technical characteristics

 Physical state: liquid · Odour: characteristic • Density: > 1 kg/L · VOC content: 0 g/L

### > Colours







### **PLEASE NOTE:**

The pigment in the various RMC Hybrid Wood Protector colours contributes to the protection of the wood from greying. The colour PURE is not pigmented, however, which will cause the natural greying to occur faster.

## › Packaging

Bottle of 20ml, 100ml and 1L, can of 5L and 20L

## › Storage

The product can be stored for up to 12 months in a dry place and in the original packaging. Do not allow to freeze.

### **APPLICATION INFORMATION**

## > Application possibilities

		MONOCOAT  MONOCO	RMC Sunprimer HWP & RMC Hybrid Wood Protector
Horizontal	Deckings	<b>✓</b>	NO
	Tables, chairs,	<b>✓</b>	NO
Vertical	Façades	<b>✓</b>	<b>√</b>
	Windows, doors,	<b>✓</b>	<b>V</b>



### TECHNICAL DATA SHEET | EXTERIOR

#### > Instructions

- **STEP 1.** Apply only on raw, totally untreated vertical wood. It is essential to remove completely all previous treatment products. Always clean the surface using RMC Exterior Wood Cleaner before starting.
- STEP 2. Stir the RMC Sunprimer HWP well. Apply a small amount of RMC Sunprimer HWP uniformly using a gun, brush, roller or cloth. Work in zones of 5 - 10 m<sup>2</sup>.
- **STEP 3.** Leave to dry for 24 hours (the surface should be dry to the touch).
- STEP 4. Now apply one coat of RMC Hybrid Wood Protector in the same colour as the RMC Sunprimer HWP you have used. Please consult the oil's user guide for how to apply this product correctly!

### > Tips

- · Always clean the wood using RMC Exterior Wood Cleaner before applying RMC Sunprimer HWP. This will significantly increase the finish's durability.
- Always use the same colour of RMC Sunprimer HWP and RMC Hybrid Wood Protector.

#### INDUSTRIAL APPLICATION

If you want to apply this product in an industrial manner, we advise you to get in contact with our technical care team. The technical data sheet for industrial use is available on demand.

For industrial applications, it is obligatory to add 10% of RMC Accelerator to the RMC Hybrid Wood Protector.

#### > Coverage

The consumption of RMC Sunprimer HWP varies according to the following parameters:

- 1. Wood density: the softer the wood, the higher the consumption.
- 2. Humidity content the wood should be dry. Don't apply if the humidity content of the wood exceeds 12%.
- 3. Ambient temperature should be between 15 °C and 27 °C, with a relative humidity of less than 80%. Do not apply in full sun or at high temperatures.
- 4. Preparation the preparation method of the wood sandpapered, brushed or shaved has an influence on the consumption.

Indication of the usage: 10 to 35 m<sup>2</sup>/L

Optimum protection is achieved by thoroughly saturating the surface being treated with RMC Sunprimer HWP. Please note: remove any excess product from the surface you are treating once the wood stops absorbing the product. RMC Sunprimer HWP may not be used as a film-forming product! Consumption may be higher when performing renovation work.

These usages are merely indicative. Results depend on wood type and method of preparation. It is always recommended to make a sample in order to calculate the exact usage.

#### > Tools












 $<sup>^{</sup>st}$ The used tools can be cleaned with RMC Cleaner.





### > Related products





Check the packaging and the safety data sheet for more details.

For our complete assortment of products for the protection and colouring of interior and exterior wood, please visit **www.rubiomonocoat.com** 

YOUR DISTRIBUTOR:

**LIABILITY:** It is the user's responsibility to establish, through his own tests, whether the product is suitable for the chosen application. In no case can Muylle Facon NV be held liable for any consequential damage. The information above may be subject to changes, which will be published in the updated versions of the technical data sheet. We cannot be held liable for poor results due to causes that are not related to the quality of the product. This technical information has been drawn up based on the currently available information and knowledge. The most recent technical data sheets can be requested or are available on the website. Date of TDS: 08/06/2017. Check the safety information before using the product.







MUYLLE 1 FACON

Muylle Facon BVBA Ambachtenstraat 58 8870 Izegem (BELGIË)

Tel. +32 (0) 51 30 80 54 Fax +32 (0) 51 30 99 78 info@muyllefacon.be

www.rubiomonocoat.com